

Siglos **ULTRA**

THE NEW UHD EXPERIENCE



RCU Codes



BEST
Bi-level Efficiency Stereo Transmitter
3D PASSIVE



3D ACTIVE
GLASSES

Dream Vision

We dream! We hope! We can!

Changes

Dreamvision provides this manual 'as is' without warranty of any kind, either expressed or implied, including but not limited to the implied warranties or merchantability and fitness for a particular purpose. Dreamvision may make improvements and/or changes to the product(s) and/or the program(s) described in this publication at any time without notice.

This publication could contain technical inaccuracies or typographical errors. Changes are periodically made to the information in this publication; these changes are incorporated in new editions of this publication.

Copyright

All right reserved. No part of this document may be copied, reproduced or translated. It shall not otherwise be recorded, transmitted or stored in a retrieval system without the prior written consent of Dreamvision.

Guarantee

Dreamvision provides a guarantee relating to perfect manufacturing as part of the legally stipulated terms of guarantee. On receipt, the purchaser must immediately inspect all delivered goods for damage incurred during transport, as well as for material and manufacturing faults. Dreamvision must be informed immediately in writing of any complaints. If the purchaser or third party carries out modifications or repairs on goods delivered by Dreamvision, or if the goods are handle incorrectly, in particular if the systems are commissioned operated incorrectly or if, after the transfer of risks, the goods are subject to influences not agreed upon in the contract, all guarantee claims of the purchaser will be rendered invalid. Not included in the guarantee coverage are system failures which are attributed to programs or special electronic circuitry provided by the purchaser, e.g. interfaces. Normal wear as well as normal maintenance are not subject to the guarantee provided by Dreamvision either.

The environmental conditions as well as the servicing and maintenance regulations specified in this manual must be complied with by the customer.

Trademarks

Brand and product names mentioned in this manual may be trademarks, registered trademarks or copyrights of their respective holders. All brands and product names mentioned in this manual serve as comments or examples and are not to be understood as advertising for the products of their manufactures.

1.1 Infra Red, long hex-pronto compatible RCU

The infrared command must be sent using NEC 5 protocol in ASCII format.

In the following example, Power ON command is 37h 33h 30h 35h, this command has to be converted as ASCII, it becomes 73 05.

To send this command using long hex Pronto compatible, convert the ASCII code as two hexadecimal numbers as follow:

Code A: 73h = 115 (for code B: 63h = 99, replace 115 by 99)

05h = 5

Then program the Pronto RCU using the Device number 115 and Function 5:

Device Code: 115 (0x73) Function: 5 (0x05):

```
0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 003C 0014
003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 0014 0014 0014 0014 0014
0014 0336
```

1.2 List of Operating commands

· Function	4	· INFO	6
· UP	4	· GAMMA	6
· DOWN.....	4	· Color.Temp.....	6
· BACK	4	· THX_Bright PM.....	7
· ON.....	4	· THX_Dark PM.....	7
· STAND BY	4	· Color Profile Menu	7
· INPUT	4	· CMD switch mode.....	7
· HIDE On/Off.....	4	· Aspect (Auto)	7
· Aperture	4	· Aspect (Native)	7
· Anamorphic(A).....	4	· Aspect (Full).....	7
· Anamorphic(Off)	4	· THX(Adjust)	7
· Aspect(4:3).....	4	· THX(Off).....	7
· Aspect(16:9).....	4	· THX(On).....	7
· Aspect(Zoom)	4	· USER 4 PM.....	7
· Anamorphic(B).....	4	· USER 5 PM.....	7
· Menu	5	· USER 6 PM.....	7
· OK.....	5	· HIDE(On)	7
· Lens	5	· HIDE(Off)	8
· RIGHT.....	5	· 3D Settings Menu	8
· LEFT	5	· 3D Format Switch	8
· CMD(Off).....	5	· Lens Memory 1	8
· CMD(Low).....	5	· Lens Memory 2	8
· CMD(High).....	5	· Lens Memory 3.....	8
· CMD(Inv. Telecine)	5	· 3D Format (Auto)	8
· ISF(Adjust).....	5	· 3D Format (SbS).....	8
· ISF(Off)	5	· 3D Format (T&B).....	8
· ISF(On)	5	· 3D Format (Off).....	8
· ISF Day PM.....	5	· Lens Memory 4	8
· ISF Night PM.....	5	· Lens Memory 5	8
· CINEMA PM.....	6	· Lens Memory 6.....	8
· FILM PM	6	· Lens Memory 7	8
· NATURAL PM	6	· Lens Memory 8.....	9
· USER 1 PM.....	6	· Lens Memory 9.....	9
· USER 2 PM.....	6	· Lens Memory 10.....	9
· USER 3 PM.....	6	· MPC Menu	9
· THX PM	6	· Picture Menu.....	9
· HDMI1	6	· Gamma Menu	9
· HDMI2.....	6	· Low Latency switch.....	9
· PIC.ADJ.....	6		
· Adv. Pict. Menu	6		

68H	104	CINEMA PM	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014
69H	105	FILM PM	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014
6AH	106	NATURAL PM	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014
6CH	108	USER 1 PM	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014
6DH	109	USER 2 PM	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014
6EH	110	USER 3 PM	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014
6FH	111	THX PM	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014
70H	112	HDMI1	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014
71H	113	HDMI2	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014
72H	114	PIC.ADJ.	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014
73H	115	Adv. Pict. Menu	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014
74H	116	INFO	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014
75H	117	GAMMA	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014
76H	118	Color.Temp.	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 0014 003C 0014 0014 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014

D1H	209	HIDE(Off)	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014
D5H	213	3D Settings Menu	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014
D6H	214	3D Format Switch	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014
D8H	216	Lens Memory 1	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014
D9H	217	Lens Memory 2	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014
DAH	218	Lens Memory 3	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014
DBH	219	3D Format (Auto)	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014
DCH	220	3D Format (SbS)	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014
DDH	221	3D Format (T&B)	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014
DEH	222	3D Format (Off)	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014
E5H	229	Lens Memory 4	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014
E6H	230	Lens Memory 5	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014
E7H	231	Lens Memory 6	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014
E8H	232	Lens Memory 7	0000 006D 0001 0011 0141 00A0 0014 003C 0014 003C 0014 0014 0014 003C 0014 003C 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014 0014 0014 003C 0014

DreamVision

WE MAKE THE WORLD DREAM

Siglos Ultra RCU Remote Codes - R699881